

Installation Guide for

Eco-Saver

Remanufactured Inkjet Cartridges




black

1 Reusable Print Head + 3 Pack Cartridges



color

1 Reusable Print Head + 3 Pack Cartridges



The first time you use this product

1 Please be noticed the reusable print head and one of the ink cartridges have been assembled together.

2 Install the ink cartridge with print head into the printer.



The second/third time you use this product



1 Remove the cartridge from the printer when it used up.

2 Detach the reusable print head from the cartridge and place it aside.

Be careful not to touch the contacts or nozzle.



3 Take out the cover of new cartridge and reassemble the reusable print head and new cartridge together.



4 After the reassembling, wipe the nozzle with tissue for 1-2 times.

5 Install the new ink cartridge with print head into the printer.

