



## MFP M283 SERIES PRINTERS

1. INSERT TONER CARTRIDGE.
2. USED OR COUNTERFEIT INSTALLED WILL APPEAR.
3. PRESS **OK** CARTRIDGE READY TO PRINT.



1. IF TONER ICON IS PRESSED, BELOW SECONDARY SCREEN WILL APPEAR INDICATING LOW TONER INSTALLED.
2. PRESS **OK** IN BOTTOM RIGHT CORNER OF SCREEN.
3. MACHINE WILL GO BACK TO **"READY"** AND WILL PRINT.



## PRO M255 SERIES PRINTERS



1. INSERT TONER CARTRIDGE.
2. SCREEN WILL INDICATE **"READY"** BUT WILL NOT DISPLAY TONER LEVEL.
3. CARTRIDGE READY TO PRINT.