

Note for Kyocera ECOSYS P6021cdn model only:

Warning, these parts are for several different models of machines. Typically, the mechanical parts are universal. However, some mechanical and electrical parts may differ from model to model and voltage type. Make sure the parts match the machine you are working on.

Locate the parts in your P6021cdn manual to see which kit to order.

Option 1

1702KV7US0 072KV7US MK-592/MAINTENANCE KIT (OPTION) 1
DV-560 US (Y) 1
DV-560 US (K) 1
DV-560 US (C) 1
DV-560 US (M) 1
PARTS HOLDER RETARD ASSY SP 1
DK-590 4
FK-590(U) 1
PARTS HOLDER RETARD ASSY SP 1
PARTS HOLDER FEED ASSY SP 1
TR-590 1
ROLLER M/P ASSY /43487B0027 A4 1

Option 2

1702KV8NL0 072KV8NL MK-590/MAINTENANCE KIT (OPTION) 1 1
DV-560(Y) 1 1
DV-560(K) 1 1
DV-560(C) 1 1
DV-560(M) 1 1
PARTS HOLDER RETARD ASSY SP 1 1
DK-590 4 4
FK-590(E) 1 1
PARTS HOLDER RETARD ASSY SP 1 1
PARTS HOLDER FEED ASSY SP 1 1
TR-590 1 1
ROLLER M/P ASSY /43487B0027 A4